



EW-D Frequency range V3-4 925.200 - 937.300 MHz

SENNHEISER

Channel	Frequency
1	925.600
2	926.200
3	926.800
4	927.400
5	928.000
6	928.600
7	929.200
8	929.800
9	930.400
10	931.000
11	931.600
12	932.200
13	932.800
14	933.400
15	934.000
16	934.600
17	935.200
18	935.800
19	936.400
20	937.000

Channel	Frequency

Channel	Frequency

Channel	Frequency

Channel	Frequency



Please contact your radio licensing authority in your country, who will advise you on the available frequencies and transmitter power requirements.
For further details see www.sennheiser.com/sifa

Informieren Sie sich bei Ihrer zuständigen Zulassungsbehörde über die erlaubten Sendefrequenzen und Sendeleistungen.
Weitere Infos finden Sie unter www.sennheiser.com/sifa